

Chapter 14:

Polymer Structures




ISSUES TO ADDRESS...

- What are the general structural and chemical characteristics of polymer molecules?
- What are some of the common polymeric materials, and how do they differ chemically?
- How is the crystalline state in polymers different from that in metals and ceramics ?



What is a Polymer?

Poly mer
many repeat unit



Adapted from Fig. 14.2, *Callister & Rethwisch 8e*.



Ancient Polymers

- Originally natural polymers were used
 - Wood
 - Rubber
 - Cotton
 - Wool
 - Leather
 - Silk
- Oldest known uses
 - Rubber balls used by Incas
 - Noah used pitch (a natural polymer) for the ark



Polymer Composition

Most polymers are hydrocarbons

– i.e., made up of H and C

- Saturated hydrocarbons

– Each carbon singly bonded to four other atoms

– Example:

- Ethane, C_2H_6





Table 14.1 Compositions and Molecular Structures for Some of the Paraffin Compounds: C_nH_{2n+2}

<i>Name</i>	<i>Composition</i>	<i>Structure</i>	<i>Boiling Point (°C)</i>
Methane	CH ₄	$ \begin{array}{c} \text{H} \\ \\ \text{H} - \text{C} - \text{H} \\ \\ \text{H} \end{array} $	-164
Ethane	C ₂ H ₆	$ \begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ \text{H} - \text{C} - \text{C} - \text{H} \\ \quad \\ \text{H} \quad \text{H} \end{array} $	-88.6
Propane	C ₃ H ₈	$ \begin{array}{c} \text{H} \quad \text{H} \quad \text{H} \\ \quad \quad \\ \text{H} - \text{C} - \text{C} - \text{C} - \text{H} \\ \quad \quad \\ \text{H} \quad \text{H} \quad \text{H} \end{array} $	-42.1
Butane	C ₄ H ₁₀		-0.5
Pentane	C ₅ H ₁₂		36.1
Hexane	C ₆ H ₁₄		69.0




Unsaturated Hydrocarbons

- Double & triple bonds somewhat unstable – can form new bonds
 - Double bond found in ethylene or ethene - C_2H_4



- Triple bond found in acetylene or ethyne - C_2H_2





Isomerism

- Isomerism


- two compounds with same chemical formula can have quite different structures

for example: C_8H_{18}

- normal-octane





- 2,4-dimethylhexane




Polymerization and Polymer Chemistry


- Free radical polymerization




- Initiator: example - benzoyl peroxide



Chemistry and Structure of Polyethylene



Adapted from Fig. 14.1, *Callister & Rethwisch 8e.*



● C ● H

Note: polyethylene is a long-chain hydrocarbon
- paraffin wax for candles is short polyethylene




Bulk or Commodity Polymers

Table 14.3 A Listing of Repeat Units for 10 of the More Common Polymeric Materials

<i>Polymer</i>	<i>Repeat Unit</i>
 Polyethylene (PE)	$\begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{H} \quad \text{H} \end{array}$
 Poly(vinyl chloride) (PVC)	$\begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{H} \quad \text{Cl} \end{array}$
 Polytetrafluoroethylene (PTFE)	$\begin{array}{c} \text{F} \quad \text{F} \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{F} \quad \text{F} \end{array}$
 Polypropylene (PP)	$\begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{H} \quad \text{CH}_3 \end{array}$

Bulk or Commodity Polymers (cont)

Table 14.3 A Listing of Repeat Units for 10 of the More Common Polymeric Materials

<i>Polymer</i>	<i>Repeat Unit</i>
 Polystyrene (PS)	$ \begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{H} \quad \text{C}_6\text{H}_5 \end{array} $
 Poly(methyl methacrylate) (PMMA)	$ \begin{array}{c} \text{H} \quad \text{CH}_3 \\ \quad \\ -\text{C}-\text{C}- \\ \quad \\ \text{H} \quad \text{C}(=\text{O})\text{OCH}_3 \end{array} $
 Phenol-formaldehyde (Bakelite)	$ \begin{array}{c} \text{OH} \\ \\ \text{CH}_2-\text{C}_6\text{H}_2-\text{CH}_2 \\ \\ \text{CH}_2 \end{array} $

Bulk or Commodity Polymers (cont)

Table 14.3 A Listing of Repeat Units for 10 of the More Common Polymeric Materials

<i>Polymer</i>	<i>Repeat Unit</i>
 Poly(hexamethylene adipamide) (nylon 6,6)	$\text{—N—}\left[\begin{array}{c} \text{H} \\ \\ \text{—C—} \\ \\ \text{H} \end{array}\right]_6\text{—N—}\overset{\text{O}}{\parallel}\text{C—}\left[\begin{array}{c} \text{H} \\ \\ \text{—C—} \\ \\ \text{H} \end{array}\right]_4\text{—}\overset{\text{O}}{\parallel}\text{C—}$
 Poly(ethylene terephthalate) (PET, a polyester)	$\text{—}\overset{\text{O}}{\parallel}\text{C—}\overset{b}{\text{C}_6\text{H}_4}\text{—}\overset{\text{O}}{\parallel}\text{C—O—}\begin{array}{c} \text{H} \quad \text{H} \\ \quad \\ \text{—C—C—} \\ \quad \\ \text{H} \quad \text{H} \end{array}\text{—O—}$
 Polycarbonate (PC)	$\text{—O—}\overset{b}{\text{C}_6\text{H}_4}\text{—}\overset{\text{CH}_3}{\underset{\text{CH}_3}{\text{C}}}\text{—}\text{C}_6\text{H}_4\text{—O—}\overset{\text{O}}{\parallel}\text{C—}$

VMSE: Polymer Repeat Unit Structures

Main Menu

Module Menu

Repeat Unit Structures

Print Main

Help

The left bar window provides a selection of repeat unit structures for ten common polymeric materials—polyethylene (PE), poly(vinyl chloride) (PVC), polytetrafluoroethylene (PTFE), polypropylene (PP), polystyrene (PS), poly(methyl methacrylate) (PMMA), phenol-formaldehyde (Bakelite), nylon 6,6, poly(ethylene terephthalate) (PET), and polycarbonate (PC). Upon selecting the label for one of these polymers,

 PE

 PVC

 PTFE

 PP

 PS

 PMMA

 Bakelite

 Nylon 6,6

 PET

 PC

Poly(vinyl chloride)


Change to FULL-SPHERE representation

 Carbon

 Hydrogen

 Chlorine

Single Repeat Unit



Manipulate and rotate polymer structures in 3-dimensions

MOLECULAR WEIGHT

- Molecular weight, M : Mass of a mole of chains.



Low M



high M


Not all chains in a polymer are of the same length
— i.e., there is a distribution of molecular weights

MOLECULAR WEIGHT DISTRIBUTION

Adapted from Fig. 14.4, *Callister & Rethwisch 8e*.

$$\bar{M}_n = \frac{\text{total wt of polymer}}{\text{total \# of molecules}}$$

$$\bar{M}_n = \sum x_i M_i$$
$$\bar{M}_w = \sum w_i M_i$$



M_i = mean (middle) molecular weight of size range i

x_i = number fraction of chains in size range i

w_i = weight fraction of chains in size range i

Molecular Weight Calculation

Example: average mass of a class

Student	Weight
	mass (lb)
1	104
2	116
3	140
4	143
5	180
6	182
7	191
8	220
9	225
10	380

What is the average weight of the students in this class:

- a) Based on the number fraction of students in each mass range?
- b) Based on the weight fraction of students in each mass range?



Molecular Weight Calculation (cont.)

Solution: The first step is to sort the students into weight ranges.
Using 40 lb ranges gives the following table:

weight range	number of students N_i	mean weight W_i
mass (lb)		mass (lb)
81-120	2	110
121-160	2	142
161-200	3	184
201-240	2	223
241-280	0	-
281-320	0	-
321-360	0	-
361-400	1	380

Calculate the number and weight fraction of students in each weight range as follows:

$$x_i = \frac{N_i}{\sum N_i} \quad w_i = \frac{N_i W_i}{\sum N_i W_i}$$

For example: for the 81-120 lb range

$$x_{81-120} = \frac{2}{10} = 0.2$$

$$w_{81-120} = \frac{2 \times 110}{1881} = 0.117$$

total
number $\rightarrow \sum N_i$
10

$\sum N_i W_i$ $\leftarrow$ total
weight
1881



Molecular Weight Calculation (cont.)

weight range	mean weight W_i	number fraction X_i	weight fraction w_i
mass (lb)	mass (lb)		
81-120	110	0.2	0.117
121-160	142	0.2	0.150
161-200	184	0.3	0.294
201-240	223	0.2	0.237
241-280	-	0	0.000
281-320	-	0	0.000
321-360	-	0	0.000
361-400	380	0.1	0.202

$$\bar{M}_n = \sum x_i M_i = (0.2 \times 110 + 0.2 \times 142 + 0.3 \times 184 + 0.2 \times 223 + 0.1 \times 380) = 188 \text{ lb}$$


$$\bar{M}_w = \sum w_i M_i = (0.117 \times 110 + 0.150 \times 142 + 0.294 \times 184 + 0.237 \times 223 + 0.202 \times 380) = 218 \text{ lb}$$

$$\bar{M}_w = \sum w_i M_i = 218 \text{ lb}$$



Degree of Polymerization, DP

DP = average number of repeat units per chain



$$DP = \frac{\overline{M}_n}{\overline{m}}$$

where $\overline{m}$ = average molecular weight of repeat unit
for copolymers this is calculated as follows:


$$\overline{m} = \sum f_i m_i$$

Chain fraction

mol. wt of repeat unit i



Molecular Structures for Polymers




Adapted from Fig. 14.7, *Callister & Rethwisch 8e*.

Polymers – Molecular Shape


Molecular Shape (or **Conformation**) – chain bending and twisting are possible by rotation of carbon atoms around their chain bonds

- note: not necessary to break chain bonds to alter molecular shape



Adapted from Fig.
14.5, Callister &
Rethwisch 8e.

Chain End-to-End Distance, r




Adapted from Fig.
14.6, Callister &
Rethwisch 8e.


Molecular Configurations for Polymers

Configurations – to change must break bonds

- Stereoisomerism



Stereoisomers are mirror images – can't superimpose without breaking a bond







Tacticity

Tacticity – stereoregularity or spatial arrangement of **R** units along chain



isotactic – all **R** groups on same side of chain

syndiotactic – **R** groups alternate sides




Tacticity (cont.)

atactic – R groups randomly positioned




cis/trans Isomerism



cis

cis-isoprene
(natural rubber)

H atom and CH₃ group on
same side of chain



trans

trans-isoprene
(gutta percha)

H atom and CH₃ group on
opposite sides of chain

VMSE: Stereo and Geometrical Isomers

[Main Menu](#) [Module Menu](#) **Stereo and Geometrical Isomers** [Print Main](#) [Help](#)

This submodule allows you to observe (in a three-dimensional perspective) and rotate (using mouse click-and-drag) the various molecular configurations for polymers: isotactic, syndiotactic, and atactic stereoisomers [for poly(vinyl chloride)]; and cis and trans geometrical isomers (for polyisoprene). (Go to "Help" for the color-coding scheme.)

PVC

 Isotactic

 Syndio

 Atactic

Polyisoprene

 Cis

 Trans


Syndiotactic Poly(vinyl chloride)

Change to FULL-SPHERE representation

 Carbon

 Hydrogen

 Chlorine



Manipulate and rotate polymer structures in 3-dimensions



Copolymers





two or more monomers
polymerized together

- **random** – A and B randomly positioned along chain
- **alternating** – A and B alternate in polymer chain
- **block** – large blocks of A units alternate with large blocks of B units
- **graft** – chains of B units grafted onto A backbone

A – ●

B – ●


Adapted from Fig.
14.9, Callister &
Rethwisch 8e.



Crystallinity in Polymers


Adapted from Fig.
14.10, Callister &
Rethwisch 8e.

- Ordered atomic arrangements involving molecular chains
- Crystal structures in terms of unit cells
- Example shown
 - polyethylene unit cell



Polymer Crystallinity


- Crystalline regions
 - thin platelets with chain folds at faces
 - Chain folded structure



Polymer Crystallinity (cont.)

Polymers rarely 100% crystalline


- Difficult for all regions of all chains to become aligned
- Degree of crystallinity expressed as **% crystallinity**.
 - Some physical properties depend on % crystallinity.
 - Heat treating causes crystalline regions to grow and % crystallinity to increase.



Adapted from Fig. 14.11, *Callister 6e*.
(Fig. 14.11 is from H.W. Hayden, W.G. Moffatt,
and J. Wulff, *The Structure and Properties of
Materials*, Vol. III, *Mechanical Behavior*, John Wiley
and Sons, Inc., 1965.)


Polymer Single Crystals

- Electron micrograph – multilayered single crystals (chain-folded layers) of polyethylene
- **Single crystals** – only for slow and carefully controlled growth rates



Adapted from Fig. 14.11, *Callister & Rethwisch 8e*.

Semicrystalline Polymers




- Some semicrystalline polymers form **spherulite** structures
- Alternating chain-folded crystallites and amorphous regions
- Spherulite structure for relatively rapid growth rates

Adapted from Fig. 14.13, *Callister & Rethwisch 8e*.

Photomicrograph – Spherulites in Polyethylene

Cross-polarized light used

-- a **maltese cross** appears in each spherulite



ANNOUNCEMENTS

Reading:

Core Problems:

Self-help Problems:

